

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THE CANDLES SHOULD TAKE APPROXIMATELY 5 MINUTES TO ASSEMBLE.

UNPACK THE CANDELS

YOU SHOULD HAVE RECEIVED (3) CANDLES AND REMOTE-CONTROL UNIT IN THE PACKAGING.

ASSEMBLY INSTRUCTIONS

1. REMOVE BATTERY COVER FROM BOTTOM OF CANDLE BODY.
2. INSTALL (2) "AAA" BATTERIES (NOT INCLUDED) INTO BATTERY BOX.
3. REPLACE BATTERY COVER TO BOTTOM OF THE CANLE FRAME.
4. FLIP ON AT POWER SWITCH.
5. REPEAT STEP 1~4 FOR THE OTHER TWO CANDLES.
6. REMOVE THE PLASTIC SHEET FROM REMOTE-CONTROL UNIT.
7. PRESS "ON" TO TURN ON THE LED LIGHT, PRESS "OFF" TO TURN OFF THE LED LIGHT.

NOTE: EFFECTIVE INFRARED OPERATION IS WITHIN 3.5 METERS.

CLEANING:

WIPE SLIGHTLY WITH SOFT CLOTH WITHOUT ANY EXCESS MOISTURE. DO NOT USE THE CLEANING LIQUID AVOIDING TO THE SURFACE DAMAGE OF CANDLE BODY. ESPECIALLY DO NOT IMMERSE IN WATER OR OTHER LIQUIDS AS THIS WILL DAMAGE THE BATTERIES AND THE CANDLE LIGHT.

CAUTIONS:

- DO NOT LEAVE THE CANDLE LIGHT OUTDOORS. IT IS NOT WATERPROOF AND CAN BE DAMAGED BY RAIN, HUMIDITY, LONG EXPOSURE TO SUNLIGHT, AND EXTREME TEMPERATURES.
- KEEP YOUR CANDLE LIGHT AWAY FROM FIRE AND HIGH TEMPERATURES.
- DO NOT PUT THE CANDLE LIGHT IN ANY LIQUIDS.
- EFFECTIVE INFRARED OPERATION IS WITHIN 3.5 METERS.
- IF YOU DO NOT WANT TO USE THESE CANDLES FOR LONG TIME, PLEASE REMOVE BATTERIES FROM BATTERY BOX.
- CHOKING HAZARD-SMALL PARTS. NOT FOR CHILDREN UNDER 3 YEARS.

TROUBLE SHOOTING

1. IF CANDLE DOES NOT LIGHT, PLEASE CHECK THE SWITCH IS LOCATED IN CORRECT POSITION AND THE BATTERIES ARE NEW AND IN CORRECT POSITION.
2. IF CANDLE STILL DOES NOT LIGHT, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.